


## Schematic & Parts List



S.No.	Description	Qty.	S.No.	Description	Qty.
1	Rubber base	1	50	Turn lever	1
2	Screw	8	51	Fixed plate	1
3	Waterproof plate	1	52	Screw	2
4	Screw	4	53	Screw	2
5	Screw	2	54	Nut	1
6	Screw	1	55	Gear	1
7	Tailgate stop	1	56	Spacer sleeve	2
8	Main base plate	1	57	Spacer plate	1
9	Waterproof gasket	1	58	Guide wheel	1
10	Splash guard	1	59	Screw	3
11	Screw	4	60	Gland	1
12	Ring	1	61	Motor side cover	1
13	Article card	1	62	Bearing	1
14	Screw	4	63	Rotor	1
15	Nut	4	64	Screw	2
16	Left holder	1	65	Spring washer	2
17	Right holder	1	66	Bearing	1
18	Fixed base for holder	2	67	Stator	1
19	Screw	4	68	Main case	1
20	Free water change injection	1	69	Brush pot	2
21	Valve	1	70	Carbon brush	2
22	Valve connection	1	71	Brush cover	2
23	Valve	1	72	Screw	2
24	Guide pillar	2	73	Bearing washer	1
25	Nut	1	74	Gland	1
26	Screw	1	75	Spring washer	2
27	Belt	1	76	Screw	2
28	Height Adjustment Shaft	1	77	Variable speed switch	1
29	Belt wheel square key	1	78	Screw	1
30	Idler	1	79	Turn button	1
31	Bearing	1	80	Nut	1
32	Bearing	1	81	Screw	2
33	Screw	2	82	Dust cover	2
34	Belt adjustable wheel	2	83	Cable sleeve	1
35	Bearing	2	84	On/Off Switch	1
36	Ring washer	2	85	Screw	3
37	Block pad	2	86	Fiber glass cover	1
38	Screw	2	87	Self-lock pin	1
39	Bearing	1	88	Spring pin	1
40	Screw	4	89	Spring	1
41	Spring washer	4	90	Dust cover	1
42	Flat washer	4	91	Screw cover	1
43	Aluminum base plate	1	92	Height adjustable knob	1
44	Guide pillar cover	4	93	Screw	1
45	Guide pillar cover	4	94	Switch sign	1
46	Bearing	1	95	Nut	1
47	Clamp spring	1	96	Dust cover	1
48	Gear	1	97	Cable	1
49	Screw	1	98	Gland	1
			102	Water Feed	1